3.5" & 5.25" SCSI/IDE EXTERNAL BOX
Installation Guide



1. PUSH THE SNAP AND PULL OUT THE DRIVE BRACKET.



FIG 2.

2. TAKE OUT THE DRIVE BRACKET FROM THE CASE BODY.



FIG 3A.

3. A: FOR CD-ROM, FLOPPY, TAPE, FLOPTICAL DRIVES, ETC:

USE OPEN FRONT PANEL FOR INSTALLING CD-ROM, FLOPPY, TAPE, FLOPTICAL DRIVES, ETC. AND THEN FASTEN THE SCREWS ON BOTH SIDES.



FIG 3B.

B: FOR HDD:
USE CLOSED FRONT PANEL FOR INSTALLING HDD AND FASTENING THE SCREWS ON BOTH SIDES.



FIG 4.

4. JOIN ALL OF THE CONNECTORS, THE DESCRIPTIONS OF CONNECTORS AS BELOWS:

COLOR	BLACK	YELLOW	BLUE	RED
ID SW	COM	4	2	1

(SCSI BOX ONLY)

COLOR	RED	BLACK
RED-LED	+	-

COLOR	RED	BLACK	WHITE
RCA JACK	RIGHT	COM	LEFT

COLOR	RED	BLACK	BLACK	YELLOW
DC POWER	+5V	COM	COM	+12V

(5.25" BOX ONLY)



FIG 5.

5. PUT THE DRIVE BRACKET, ASSEMBLED WITH THE DRIVE, BACK TO THE CASE BODY (EASY SLIDE-BACK IN INSTALLATION).



FIG 6.

6. A: TURN THE CASE BODY UP-SIDE-DOWN, PULL OUT THE RUBBER FEET, THEN FASTEN SCREWS TO AFFIX THE DRIVE BRACKET TO THE CASE BODY.

B: TO REMOVE THE DRIVE BRACKET, PULL OUT THE RUBBER FEET AND REVERSE THE ABOVE PROCEDURE.



FIG 7.

7. AT-BUS/IDE PIN ASSIGNMENT AND CONNECTOR INTERFACE.
(IDE BOX ONLY)

Specification & configuration is subject to change without notice